

Door Service Checklist

AlluGuard roller garage doors should be regularly serviced by a competent person. We recommend that you enter into a service agreement with the company that installed your door.

A full door service should include the following at a minimum:

Check exterior of curtain for debris/salt/dirt signs of rubbing or scuffing - clean as required. Advisory notes:
Check operation on all handsets and wall station buttons/ change batteries after 18 months or second service. Advisory notes:
Check bottom safety edge operations and condition of bottom rubber seal / change battery after 18 months or on second service. Advisory notes:
Remove back box and check straps and rings haven't moved or become loose and fur still in place. Advisory notes:
Check bottom and top limits of operator haven't crept forward reset if necessary. Advisory notes:
Check top laths haven't moved left /right or lost end caps - adjust and re fix as required. Advisory notes:
Check safety brake is free of debris all fixings are tight. Advisory notes:
Check end plate fixings - must have at least two good solid fixing each side check rollers and guide fur are in good order and clean. Advisory notes:
Clean any debris from hood replace and check manual winder operation check eye is in line with motor and not causing stress. Advisory notes:
Change batteries in safety edge if wireless after 18 months or on second service. Advisory notes:
Change batteries in handsets after 18 months or on second service. Advisory notes:
Inspect bulb and change if required. Ensure no debris in bulb holder. Advisory notes:
Operate door and check for rubbing / scuffing and ensure guides are clean. Advisory notes:
Check all Fixing points on the guides. Advisory notes:
Check top and bottom magnets are in place and operating correctly. Advisory notes:
Check power supply cable is secured and in good order. Check control box is not on a damp wall, fit spacers if required. Advisory notes:
Test safety edge for function. Advisory notes: